Manual Edifier 1.0, Aug. 2019
BL-QS-S2000MK-00

Edifier International Limited
P.O. Box 2214
General Post Office
Hong Kong

Tel: +852 2521 6989
Fax: +852 2521 7383
www.edifier.com
© Edifier International Limited. All rights reserved.
Printed in China

NOTES:
For the need of technical improvement and system upgrade, information contained herein may be subject to change from time to time without notice.
Products of EDIFIER will be customized for different applications. Pictures and illustrations shown on the manual may be slightly different from actual product. Picture for reference only, actual product prevails.

EDIFIER®

S2000MK III

Powered Bookshelf Speakers

User manual | Manuel d'utilisateur | Manual de usuario | Bedienungsanleitung | Manuale dell'utente | Manual do utilizador

名　　称：	S2000MKⅢ（英法西德意葡）说明书		东莞市漫步者科技有限公司	
材　　质：	80g书纸（封面和底面用100g书纸） 对折，胶装			
尺　　寸：	127×127（MM）	校　　对：		
版本号及料号：	V1.0/IB-200-S2000H-00	批　　准：		

IB-200-S2000H-00 说明书S2000MKⅢ/英法西德意葡

Important safety instruction

English

1. Please read the instructions carefully. Keep it in safe place for future reference.
2. Keep the unit away from moisture and heat.
3. Install the equipment according the following the instructions in the device connection section.
4. Using the product in a 25°C environment is recommended.
5. Do not block any ventilation openings. Ensure adequate ventilation for cool ventilation.
6. Do not use the product near water. Do not damage the product when the equipment is exposed to dripping or splashing.
7. Do not place any sources of naked flames, such as candles, on the product. Do not place objects filled with liquids, such as vases, on the product.
8. Do not place any object filled with liquids, such as vases on the product, neither should any open fire, such as lighted candles and electric heaters.
9. Do not block any ventilation openings. Do not insert any object into ventilation openings or slots. It may cause fire or electric shock.
10. Only sufficient clearance around the product to maintain good ventilation (minimum 5cm is recommended).
11. Do not force or plug into the jack. Before connection, check for the leakage in the jack and whether the plug matches the jack and is oriented to the right direction.
12. Do not use the product in damp conditions (such as indoor) away from children to prevent from being swallowed by mistake.
13. Do not spray or remove the housing yourself. It may expose you to dangerous voltage or other hazardous risks. Regardless the cause of damage (such as damaged wire or plug, exposure to liquid splash or foreign object falling in), exposure to rain or moisture, abnormal operation or dropping, please refer to the warranty card and contact your nearest professional maintenance.
14. Please unplug the power cord during a storm or lightning, also, please turn off the power and disconnect the power plug first.
15. Never use strong acid, alkali, gasoline, alcohol, or other chemical solvents to clean the product surface. Use only neutral cleaner or clean wash for cleaning.

Excessively loud music may lead to hearing loss. Please keep the volume in a safe range.

Correct Disposal of this product: This marking indicates that this product should not be disposed with other household wastes throughout the EU. To prevent possible harm to the environment or human health from uncontrolled waste disposal, recycle it responsibly to promote the sustainable reuse of material resources. To return your used device, please use the return and collection systems or contact the retailer where the product was purchased. They can take this product for environmental safe recycling.

We only with the cart, stand, tripod, bracket, or table specified by the manufacturer, or sold with the apparatus. When a cart is used, use caution when moving the cart/apparatus combination to avoid injury from tip-over.

Important safety instruction

Power warning:
1. Please make sure you adjust near the power outlet for easy use.
2. Before use, make sure that the operating voltage is the same as your local power supply. Correct operating voltage can be found under the product label.
3. For safety purpose, unplug the product during lightning storms or when unused for extended periods of time.
4. To disconnect the power supply completely, the power supply must be disconnected from the wall outlet.
5. Caution

The symbol is to alert the user to the presence of uninsulated dangerous voltage within the product's enclosure that may be sufficient magnitude to constitute a risk of electric shock to persons.

Read carefully the owner's manual. The symbol is to alert the user to the presence of important operating and maintenance (servicing) instructions in the literature accompanying the appliance.

The symbol indicates that the product is a CLASS II or double insulated electrical device with no earth requirement.

The RMMS plug is used as the disconnect device. We disconnect device shall remain readily operable.

For wireless product:
1. Please switch off the transmitter whenever there're radio frequencies and interfere with the normal use of other electronic devices or medical equipment.
2. Turn off the product when it's disabled. Do not use the product in medical facilities, on airplanes, at gas stations, near blasting areas or in other areas where the use of wireless devices is prohibited.
3. Do not use the product in the vicinity of a pacemaker within a 20cm range. The radio waves may affect the normal operation of the pacemaker or other medical devices.

Consignes de sécurité importantes

French

1. Lisez toutes ces instructions avec attention. Conservez-les en un lieur segura como référence futura.
2. Tenez l'appareil à l'écart de l'humidité et de la chaleur.
3. Installez le produit conformément aux consignes de la section des connexions dans la section concernant la connexion de l'appareil.
4. Il est recommandé d'utiliser le produit dans un environnement à 25°C.
5. Pour réduire le risque d'incendie ou d'électrocution, ne pas exposer le produit à la pluie ou à l'humidité.
6. Ne pas utiliser l'appareil à proximité de l'eau. Ne pas endommager le produit dans l'eau si l'appareil a été éclaboussé ou a été exposé à la pluie.
7. Ne placez pas de sources de flammes nues, telles que des bougies, sur le produit. Ne placez pas d'objets remplis de liquides, tels que des vases, sur le produit.
8. Ne pas poser d'objet rempli d'eau, comme un vase sur le produit. Ne pas y déposer de source de flamme nue, comme des bougies allumées ou des appareils de chauffage électriques.
9. Ne pas obstruer les ouvertures de ventilation. Ne pas insérer d'objets dans les ouvertures de l'appareil. Cela pourrait provoquer un incendie ou un choc électrique.
10. Ne pas forcer ou brancher de force sur la prise. Avant de brancher un câble, assurez-vous que la prise est correctement connectée et que la fiche est orientée dans le bon sens.
11. Ne pas utiliser le produit dans des conditions humides (comme à l'intérieur) pour éviter que des enfants ne l'avalent par erreur.
12. Ne pas pulvériser ou retirer le boîtier vous-même. Cela pourrait vous exposer à des tensions dangereuses ou à d'autres risques. Quelle que soit la cause du dommage (un câble ou une prise endommagé, la mise en contact avec du liquide, la pluie ou l'humidité, un fonctionnement anormal ou une chute), veuillez vous référer à la garantie et contacter votre service de maintenance professionnel le plus proche.
13. Veuillez débrancher le cordon d'alimentation pendant un orage ou un éclair, et également éteindre l'alimentation et débrancher la fiche d'alimentation.
14. Ne jamais utiliser d'acide fort, d'alcalin, d'essence, d'alcool ou d'autres solvants chimiques pour nettoyer la surface du produit. Utilisez uniquement un détergent neutre ou un nettoyage à sec pour le nettoyage.
15. Une musique trop forte peut entraîner une perte auditive. Veuillez maintenir le volume dans une plage sûre.

Élimination correcte de ce produit : Ce marquage indique que ce produit ne doit pas être jeté avec les autres déchets ménagers dans l'UE. Pour éviter tout dommage potentiel à l'environnement ou à la santé humaine dû à l'élimination incontrôlée des déchets, recyclez-le de manière responsable afin de promouvoir la réutilisation durable des ressources matérielles. Pour retourner votre appareil usagé, veuillez utiliser les systèmes de retour et de collecte ou contactez le vendeur du produit qui peut prendre en charge ce produit pour un recyclage respectueux de l'environnement.

N'utilisez qu'avec le pied, le support, le trépied, le crochet ou la table répondu par le fabricant ou vendu avec l'appareil. Lorsqu'un chariot est utilisé, faites preuve de prudence lors du déplacement d'un ensemble chariot/appareil afin d'éviter des blessures dues au renversement à un poste de pilotage.

Consignes de seguridad importantes

Spanish

1. Lea todas las instrucciones con atención. Consérvelas en un lugar seguro como referencia en el futuro.
2. Mantenga la unidad alejada de la humedad y el calor.
3. Instale el producto conforme a las instrucciones descritas en la sección conectada a conexión del dispositivo.
4. Se recomienda usar el producto en un entorno de 25°C.
5. No bloquee ninguna abertura de ventilación. Asegúrese de que la ventilación sea adecuada para mantener una buena ventilación.
6. No use el producto cerca del agua. No dañe el producto cuando el equipo esté expuesto a goteos o salpicaduras.
7. No coloque ninguna fuente de llama desnuda, como velas, encima del producto. No coloque objetos llenos de líquidos, como jarrones, encima del producto.
8. No coloque ningún objeto lleno de líquidos, como jarrones, encima del producto, ni tampoco ningún fuego abierto, como velas encendidas y estufas eléctricas.
9. No bloquee ninguna abertura de ventilación. No inserte ningún objeto en las aberturas de ventilación o en las ranuras. Podría provocar un incendio o una descarga eléctrica.
10. Solo una distancia suficiente alrededor del producto para mantener una buena ventilación (se recomienda un mínimo de 5 cm).
11. No fuerce ni conecte a la fuerza. Antes de conectar, compruebe si existen obstrucciones en la toma y si el conector coincide con la toma y está orientado en la dirección correcta.
12. No utilice el producto en condiciones húmedas (como en interiores), alejado de los niños para evitar que se lo traguen por error.
13. No rocíe ni retire la carcasa usted mismo. Podría exponerse a tensión peligrosa u otros riesgos. Independientemente de la causa de los daños (como un cable o enchufe dañado, exposición a salpicaduras de líquidos o a objetos extraños, exposición a la lluvia o a la humedad, funcionamiento no apto para el uso, etc.), o